

Lubrication plan



Fig. 191 Shown with Powertilt and hydraulic Easy Lock quickhitch (option)



Position	Lubrication point	Interval	Quantity
1.	Boom	Daily	2
2.	Stick cylinder	Daily	2
3.	Bucket cylinder	Daily	3
4.	Boom cylinder	Daily	2
5.	Joint rod	Daily	1
6.	Bucket pin	Daily	2
7.	Shovel arm	Daily	1
8.	Swiveling console	Daily	2
9.	Stabilizer blade	Every week	4
10.	Ball bearing race	Every week	1
11.	Swiveling cylinder	Daily	2
12.	Control lever base	Every week	3
13.	Hydraulic quickhitch (option)	Daily	2
14.	Powerlift (option)	Daily	4

Green grease nipples mean: lubrication every 50 hours or once a week.

Blue grease nipples mean: lubrication every 10 hours or daily.